

# VON DUPRIN®

## Installation Instructions



931227-00

### STRIKEFORCE® 6211/6211DS Electric Strike

#### Single Door Mortise or Cylindrical Application



**Notes:** Deadbolt will not function with this strike.  
Check with factory for retrofit applications.

1. For lock or device preparation, see their directions.
2. Prepare frame for strike (see other side).
3. Wire strike (Figure 1). (Switches on 6211DS only.)

4. Install insert for auxiliary bolt operation (Figure 2).
5. Test strike: Apply solenoid power. Fail secure (FSE) lip unlocks. Fail safe (FS) lip locks. Figure 1 shows status of switches.
6. Install strike with two #12-24 screws. Make sure clearance between latch bolt and strike lip is 1/32" (Figure 3). If not, uninstall strike, adjust (Figure 4), and reinstall.
7. If latch bolt does not extend far enough to actuate tripper, install extension (Figure 5). (Tripper on 6211DS only.)
8. Test door: With strike unlocked, door opens with latch bolt extended. When door closes, latch bolt rides over strike lip.




Figure 1




Figure 2




Figure 3




Figure 4







Figure 5



**Frame Preparation for Strike**



**Strike Dimensions and Required Clearances**