



INSTRUCTIONS:

1. OPEN DOOR TO DESIRED POSITION.
2. PLACE STRIKE AND HOLDER IN DESIRED LOCATION.
3. LOCATE THE MOUNTING HOLES.
4. PREPARE MOUNTING HOLES AS NECESSARY.
5. INSTALL BODY AND STRIKE.

NOTES:

1. METAL DOORS SHOULD BE PROPERLY REINFORCED WITH 3/16\"/>

	QTY	SCREW DETAILS
W20 BODY	3	#10 X 1\"/>
	3	PLASTIC EXP SHIELD
W20X BODY	1	5/16\"/>
	1	LEAD EXP SHIELD
	1	#10 X 1\"/>
	1	PLASTIC EXP SHIELD
STRIKE	2	#10 X 1\"/>



**WS20 & WS20X MANUAL WALL HOLDER
INSTALLATION INSTRUCTION**



NOTE: DIMENSIONS IN () ARE MILLIMETERS.

TEMPLATE NUMBER: INST.WS20_0

DATE:
09-01-01